

## Measuring kit instructions

- Apply release agent PAT 2024 on both surfaces, let it sit for 5 minutes.
- All surfaces has to be coated to release the hot melt from the surface
- Place the box in the packaging machine and mark the box/boxes for easy removal
- **Note ! The box is open from the flaps/corners when remowing it from the line!**
- You can now clearly see the positioning, bead size, amount, etc to correct settings if needed
- Remove the hot melt from the box and place the hot melt on the scale
- Repeat the measurement as many times if needed.
- The release agent is non-toxic and can be used for indirect food contact

FOR INFO/RE-ORDER: [www.proamtec.com](http://www.proamtec.com)

PATENT PENDING

LET'S SAVE MONEY AND HOT MELT, THE ENVIRONMENT WILL  
THANK YOU!

